

Selection Guide

Appearance	Product Series	Mounting Hole	Contact rating	Contact	Function	Page
 NEW Models	AP	ø8mm, ø10mm, ø12mm, ø16mm	N/A	N/A	Pilot light	442
	A8	ø8mm	1A	Fixed	Pushbutton, Pilot Light	446
 NEW Models	XA		5A	Removable	E-Stop	451
	A6	ø16mm	1A	Fixed	Pushbutton, Pilot Light, Selector Switch, Key Switch, E-Stop	457
	L6		5A	Removable	Pushbutton, Pilot Light, Selector Switch, Key Switch, E-Stop, Buzzer	471
 NEW Models	XW		5A	Removable	E-Stop	494
	HW		10A	Removable	Pushbutton, Pilot Light, Selector Switch, Key Switch, E-Stop, MonoLever	500
	TW	ø22mm	10A	Removable	Pushbutton, Pilot Light, Selector Switch, Key Switch, E-Stop	561
 NEW	FB		N/A	N/A	Enclosures	602

Switches & Pilot Lights

Display Lights

Relays & Sockets

Timers

Terminal Blocks

Circuit Breakers

Selection Guide con't

Appearance	Product Series	Mounting Hole	Contact rating	Contact	Function	Page
	XN	ø30mm	5A	Removable	E-Stop	604
	TWTD		10A	Removable	Pushbutton, Pilot Light, Selector Switch, Key Switch, E-Stop	610
	CS		10A	fixed	Cam Switch	640
	ARN		10A	Removable	MonoLever	647
	LW Silhouette		ø25mm, □ 25 x 25mm	5A	Removable	Pushbutton, Pilot Light, Selector Switch, Key Switch

Switches & Pilot Lights

Display Lights

Relays & Sockets

Timers

Terminal Blocks

Circuit Breakers